

Manual | EN

# PLC Library: TcNCDrive

TwinCAT 2 | TX1200, PlcNc, TcNcUtilities



TwinCAT Motion





# Table of contents

<b>1 Foreword .....</b>	<b>5</b>
1.1 Notes on the documentation.....	5
1.2 Safety instructions .....	6
<b>2 POU's of TcNcDrive.lib.....</b>	<b>7</b>
<b>3 General SoE FB.....</b>	<b>9</b>
3.1 FB_SoEReset.....	9
3.2 FB_SoEWritePassword .....	10
3.3 Command FB .....	11
3.3.1 FB_SoEExecuteCommand.....	11
3.3.2 FB_SoEWriteCommandControl.....	13
3.3.3 FB_SoEReadCommandState.....	14
3.4 Diagnosis FB .....	16
3.4.1 FB_SoEReadDiagMessage.....	16
3.4.2 FB_SoEReadDiagNumber.....	17
3.4.3 FB_SoEReadDiagNumberList.....	18
3.4.4 FB_SoEReadClassXDiag.....	20
3.5 FB for current values .....	21
3.5.1 FB_SoERead.....	21
3.5.2 FB_SoEWrite.....	23
3.5.3 FB_SoEReadAmplifierTemperature .....	24
3.5.4 FB_SoEReadMotorTemperature.....	26
3.5.5 FB_SoEReadDcBusCurrent .....	27
3.5.6 FB_SoEReadDcBusVoltage.....	28
<b>4 AX5000 specific FB .....</b>	<b>30</b>
4.1 FB_SoEAX5000ReadActMainVoltage.....	30
4.2 FB_SoEAX5000SetMotorCtrlWord.....	31
4.3 FB_SoEAX5000FirmwareUpdate.....	32
<b>5 F_GetVersionTcNcDrive .....</b>	<b>36</b>
<b>6 E_FwUpdateState .....</b>	<b>37</b>



# 1 Foreword

## 1.1 Notes on the documentation

This description is only intended for the use of trained specialists in control and automation engineering who are familiar with applicable national standards.

It is essential that the documentation and the following notes and explanations are followed when installing and commissioning the components.

It is the duty of the technical personnel to use the documentation published at the respective time of each installation and commissioning.

The responsible staff must ensure that the application or use of the products described satisfy all the requirements for safety, including all the relevant laws, regulations, guidelines and standards.

### Disclaimer

The documentation has been prepared with care. The products described are, however, constantly under development.

We reserve the right to revise and change the documentation at any time and without prior announcement. No claims for the modification of products that have already been supplied may be made on the basis of the data, diagrams and descriptions in this documentation.

### Trademarks

Beckhoff®, TwinCAT®, TwinCAT/BSD®, TC/BSD®, EtherCAT®, EtherCAT G®, EtherCAT G10®, EtherCAT P®, Safety over EtherCAT®, TwinSAFE®, XFC®, XTS® and XPlanar® are registered trademarks of and licensed by Beckhoff Automation GmbH.

Other designations used in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owners.

### Patent Pending

The EtherCAT Technology is covered, including but not limited to the following patent applications and patents:

EP1590927, EP1789857, EP1456722, EP2137893, DE102015105702  
with corresponding applications or registrations in various other countries.



EtherCAT® is a registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany

### Copyright

© Beckhoff Automation GmbH & Co. KG, Germany.

The reproduction, distribution and utilization of this document as well as the communication of its contents to others without express authorization are prohibited.

Offenders will be held liable for the payment of damages. All rights reserved in the event of the grant of a patent, utility model or design.

## 1.2 Safety instructions

### Safety regulations

Please note the following safety instructions and explanations!  
Product-specific safety instructions can be found on following pages or in the areas mounting, wiring, commissioning etc.

### Exclusion of liability

All the components are supplied in particular hardware and software configurations appropriate for the application. Modifications to hardware or software configurations other than those described in the documentation are not permitted, and nullify the liability of Beckhoff Automation GmbH & Co. KG.

### Personnel qualification

This description is only intended for trained specialists in control, automation and drive engineering who are familiar with the applicable national standards.

### Description of symbols

In this documentation the following symbols are used with an accompanying safety instruction or note. The safety instructions must be read carefully and followed without fail!

#### DANGER

##### **Serious risk of injury!**

Failure to follow the safety instructions associated with this symbol directly endangers the life and health of persons.

#### WARNING

##### **Risk of injury!**

Failure to follow the safety instructions associated with this symbol endangers the life and health of persons.

#### CAUTION

##### **Personal injuries!**

Failure to follow the safety instructions associated with this symbol can lead to injuries to persons.

#### **NOTE**

##### **Damage to the environment or devices**

Failure to follow the instructions associated with this symbol can lead to damage to the environment or equipment.



##### **Tip or pointer**

This symbol indicates information that contributes to better understanding.

## 2 POU's of TcNcDrive.lib

This library contains functions and functionblocks for SoE-drives. The access to the drive is done via NC-Axis-Reference (NC\_TO\_PLC).

The TcNcDrive.lib contains Wrapper-FBs around the FBs of the TcDrive.lib.

There are differences in the usage of the Drive libs in combination with AX5000 and with Bosch Rexroth IndraDriveCS. See samples.

### TcNcDrive.lib

The TcNcDrive.lib should be used, if the drive is used with the NC via FBs of the libraries TcNc.lib or TcMc.lib. The FBs of the TcNcDrive.lib use the information of the NC-Axis structure (NC\_TO\_PLC), that are also used by the FBs of the TcNc.lib or TcMc.lib. The FBs determine via the Nc-AxisID of the NC\_TO\_PLC structure the access data to the drive (NetID, address and channel number). See samples of the FBs in the documentation of the TcNcDrive.lib.

Hint: The function blocks FB\_SoERead and FB\_SoEWrite can be used to access any parameter in the drive, that have no special acces FB.

### Functions

Name	Description
F_GetVersionTcNcDrive [ <a href="#">▶ 36</a> ]	This function can be used to read the version information of the PLC library.
F_ConvWordToSTAX5000C1D	See documentation of TcDrive.lib  Converts the C1D-Word (S-0-0011) of an AX5000 to a structure ST_AX5000_C1D

### Functionblocks

Name	Description
FB_SoEReset [ <a href="#">▶ 9</a> ]	Execute drive reset (S-0-0099)
FB_SoEWritePassword [ <a href="#">▶ 10</a> ]	Set drive password (S-0-0267)
FB_SoEReadDiagMessage [ <a href="#">▶ 16</a> ]	Read diagnostic message (S-0-0095)
FB_SoEReadDiagNumber [ <a href="#">▶ 17</a> ]	Read diagnostic number (S-0-0390)
FB_SoEReadDiagNumberList [ <a href="#">▶ 18</a> ]	Read diagnostic number list (up to 30 entries) (S-0-0375)
FB_SoEReadClassXDiag [ <a href="#">▶ 20</a> ]	Read class 1 diag (S-0-0011) ... class 3 diag (S-0-0013)
FB_SoEExecuteCommand [ <a href="#">▶ 11</a> ]	Execute command
FB_SoEWriteCommandControl [ <a href="#">▶ 13</a> ]	Set command control
FB_SoEReadCommandState [ <a href="#">▶ 14</a> ]	Read command state
FB_SoERead [ <a href="#">▶ 21</a> ]	Read parameter
FB_SoEWrite [ <a href="#">▶ 23</a> ]	Write parameter

Name	Description
FB_SoEReadAmplifierTemperature [ <a href="#">▶ 24</a> ]	Read amplifier temperature (S-0-0384)
FB_SoEReadMotorTemperature [ <a href="#">▶ 26</a> ]	Read motor temperature (S-0-0383)
FB_SoEReadDcBusCurrent [ <a href="#">▶ 27</a> ]	Read Dc-Bus-current (S-0-0381)
FB_SoEReadDcBusVoltage [ <a href="#">▶ 28</a> ]	Read Dc-Bus-Voltage (S-0-0380)
FB_SoEAX5000ReadActMainVoltage [ <a href="#">▶ 30</a> ]	Read main voltage (P-0-0200)
FB_SoEAX5000SetMotorCtrlWord [ <a href="#">▶ 31</a> ]	Set motor control word to override brake handling (P-0-0096)
FB_SoEAX5000FirmwareUpdate [ <a href="#">▶ 32</a> ]	Automatic firmware update of AX5000

### Sample project and configuration for AX5000 drive diagnose

See <https://infosys.beckhoff.com/content/1033/tcplclibncdrive/Resources/pro/10954810635.pro>, <https://infosys.beckhoff.com/content/1033/tcplclibncdrive/Resources/tsm/10954813579.tsm>

### Sample project and configuration for IndraDriveCS drive diagnose

See <https://infosys.beckhoff.com/content/1033/tcplclibncdrive/Resources/pro/10954814987.pro>, <https://infosys.beckhoff.com/content/1033/tcplclibncdrive/Resources/tsm/10954816395.tsm> (TcNcDrive.lib v0.0.25 or higher)

### Requirements


#### Requirements

Component	Version
TwinCAT on the development PC	2.10 Build 1335 or higher
TwinCAT on the Windows CE-Image	2.10 Build 1333 or higher
TwinCAT on the Windows XP-Image	2.10 Build 1333 or higher




### 3 General SoE FB

#### 3.1 FB\_SoEReset



The functionblock FB\_SoEReset can be used to execute a drive reset (S-0-0099). Drives with more than on channel may require a reset on all channels. The timeout time must be 10s, because the reset can take up to 10s.

For the AX5000 the flag "Wait For WcState is OK" in the Advanced EtherCAT Settings has to be active.



An NC-Reset is not executed.

If an NC-Reset is necessary it can be executed via the MC\_Reset block from the TcMc.lib

#### VAR\_INPUT

```
VAR_INPUT
  sNetId : T_AmsNetId := '';
  bExecute : BOOL;
  tTimeout : TIME := DEFAULT_ADS_TIMEOUT;
END_VAR
```

**sNetId:** A string containing the AMS network identifier of the PC.

**bExecute:** The block is activated by a rising edge at this input.

**tTimeout:** Maximum time allowed for the execution of the function block.

#### VAR\_IN\_OUT

```
VAR_IN_OUT
  Axis : NCTOPLC_AXLESTRUCT; (* reference to NC axis *)
END_VAR
```

**Axis:** Axis structure.

**VAR\_OUTPUT**

```
VAR_OUTPUT
  bBusy      : BOOL;
  bError     : BOOL;
  iAdsErrId  : UINT;
  iSercosErrId : UINT;
END_VAR
```

**bBusy:** This output is set when the function block is activated, and remains set until an acknowledgement is received.

**bError:** This output is set up after the bBusy output has been reset if there has been an error in transmission of the command.


**iAdsErrId:** Supplies the ADS error code associated with the most recently executed command if the bError output is set.

**iSercosErrId:** Supplies the Sercos error code associated with the most recently executed command if the bError output is set.

**Sample**

```
fbSoEReset : FB_SoEReset_ByDriveRef;
bSoEReset : BOOL;

(* NcAxis *)
stNcToPlc AT %I* : NCTOPLC_AXLESTRUCT;
IF bSoEReset THEN
  fbSoEReset(
    Axis      := stNcToPlc,
    bExecute  := TRUE,
    tTimeout  := DEFAULT_ADS_TIMEOUT,
  );
IF NOT fbSoEReset.bBusy THEN
  fbSoEReset(Axis := stNcToPlc, bExecute := FALSE);
  bSoEReset := FALSE;
END_IF
END_IF
```

**3.2 FB\_SoEWritePassword**

The functionblock FB\_SoEWritePassword can be used to set the drive password (S-0-0267).

**VAR\_INPUT**

```
VAR_INPUT
  sNetId      : T_AmsNetId := '';
  bExecute    : BOOL;
  tTimeout    : TIME := DEFAULT_ADS_TIMEOUT;
  sPassword   : ST_SoE_String;
END_VAR
```

**sNetId:** A string containing the AMS network identifier of the PC.

**bExecute:** The block is activated by a rising edge at this input.

**tTimeout:** Maximum time allowed for the execution of the function block.

**sPassword:** Contains password as Sercos string

**VAR\_IN\_OUT**

```
VAR_IN_OUT
  Axis : NCTOPLC_AXLESTRUCT; (* reference to NC axis *)
END_VAR
```

**Axis:** Axis structure.

**VAR\_OUTPUT**

```
VAR_OUTPUT
  bBusy      : BOOL;
  bError     : BOOL;
  iAdsErrId  : UINT;
  iSercosErrId : UINT;
END_VAR
```

**bBusy:** This output is set when the function block is activated, and remains set until an acknowledgement is received.

**bError:** This output is set up after the bBusy output has been reset if there has been an error in transmission of the command.

**iAdsErrId:** Supplies the ADS error code associated with the most recently executed command if the bError output is set.

**iSercosErrId:** Supplies the Sercos error code associated with the most recently executed command if the bError output is set.

**Sample**

```
fbWritePassword : FB_SoEWritePassword;
bWritePassword  : BOOL;
sPassword       : ST_SoE_String;

(* NcAxis *)
stNcToPlc AT %I* : NCTOPLC_AXLESTRUCT;
IF bWritePassword THEN
  fbWritePassword(
    Axis      := stNcToPlc,
    bExecute  := TRUE,
    tTimeout  := DEFAULT_ADS_TIMEOUT,
    sPassword := sPassword
  );
  IF NOT fbWritePassword.bBusy THEN
    fbWritePassword(Axis := stNcToPlc, bExecute := FALSE);
    bWritePassword := FALSE;
  END_IF
END_IF
```

**3.3 Command FB**

**3.3.1 FB\_SoEExecuteCommand**



The functionblock `FB_SoEExecuteCommand` can be used to execute a command.

**VAR\_INPUT**

```
VAR_INPUT
  sNetId   : T_AmsNetId := '';
  nIdn     : WORD;
  bExecute : BOOL;
  tTimeout : TIME := DEFAULT_ADS_TIMEOUT;
END_VAR
```

**sNetId:** A string containing the AMS network identifier of the PC.

**nIdn:** Parameter number for the command, i.e. "P\_0\_IDN + 160" for executing a P-0-0160 command

**bExecute:** The block is activated by a rising edge at this input.

**tTimeout:** Maximum time allowed for the execution of the function block.

**VAR\_IN\_OUT**

```
VAR_IN_OUT
  Axis : NCTOPLC_AXLESTRUCT; (* reference to NC axis *)
END_VAR
```

**Axis:** Axis structure.

**VAR\_OUTPUT**

```
VAR_OUTPUT
  bBusy       : BOOL;
  bError      : BOOL;
  iAdsErrId   : UINT;
  iSercosErrId : UINT;
END_VAR
```

**bBusy:** This output is set when the function block is activated, and remains set until an acknowledgement is received.

**bError:** This output is set up after the bBusy output has been reset if there has been an error in transmission of the command.

**iAdsErrId:** Supplies the ADS error code associated with the most recently executed command if the bError output is set.


**iSercosErrId:** Supplies the Sercos error code associated with the most recently executed command if the bError output is set.

**Sample**

```
fbExecuteCommand : FB_SoEExecuteCommand;
bExecuteCommand  : BOOL;
nIdn             : WORD;

(* NcAxis *)
stNcToPlc AT %I* : NCTOPLC_AXLESTRUCT;
IF bExecuteCommand THEN
  nIdn := P_0_IDN + 160;
  fbExecuteCommand(
    Axis       := stNcToPlc,
    bExecute   := TRUE,
    tTimeout   := DEFAULT_ADS_TIMEOUT,
    nIdn       := nIdn,
  );
  IF NOT fbExecuteCommand.bBusy THEN
    fbExecuteCommand(Axis := stNcToPlc, bExecute := FALSE);
    bExecuteCommand := FALSE;
  END_IF
END_IF
```

### 3.3.2 FB\_SoEWriteCommandControl



The functionblock FB\_SoEWriteCommandControl can be used to prepare, start or cancel a command.

#### VAR\_INPUT

```
VAR_INPUT
  sNetId      : T_AmsNetId := '';
  nIdn       : WORD;
  eCmdControl : E_SoE_CmdControl;
  bExecute   : BOOL;
  tTimeout   : TIME := DEFAULT_ADS_TIMEOUT;
END_VAR
```

**sNetId:** A string containing the AMS network identifier of the PC.

**nIdn:** Parameter number for the command, i.e. "P\_0\_IDN + 160" for executing a P-0-0160 command

**eCmdControl:** prepare a command with eSoE\_CmdControl\_Set := 1, execute a command with eSoE\_CmdControl\_SetAndEnable := 3 or abort a command with eSoE\_CmdControl\_Cancel := 0

**bExecute:** The block is activated by a rising edge at this input.

**tTimeout:** Maximum time allowed for the execution of the function block.

#### VAR\_IN\_OUT

```
VAR_IN_OUT
  Axis : NCTOPLC_AXLESTRUCT; (* reference to NC axis *)
END_VAR
```

**Axis:** Axis structure.

#### VAR\_OUTPUT

```
VAR_OUTPUT
  bbBusy      : BOOL;
  bError      : BOOL;
  iAdsErrId   : UINT;
  iSercosErrId : UINT;
END_VAR
```

**bBusy:** This output is set when the function block is activated, and remains set until an acknowledgement is received.

**bError:** This output is set up after the bBusy output has been reset if there has been an error in transmission of the command.

**iAdsErrId:** Supplies the ADS error code associated with the most recently executed command if the bError output is set.

**iSercosErrId:** Supplies the Sercos error code associated with the most recently executed command if the bError output is set.


**Sample**

```

fbWriteCommandControl : FB_SoEWriteCommandControl;
bWriteCommandControl  : BOOL;
nIdn                  : WORD;
eCmdControl           : E_SoE_CmdControl;

(* NcAxis *)
stNcToPlc AT %I* : NCTOPLC_AXLESTRUCT;
IF bWriteCommandControl THEN
  nIdn := P_0_IDN + 160;
  fbWriteCommandControl(
    Axis      := stNcToPlc,
    bExecute  := TRUE,
    tTimeout  := DEFAULT_ADS_TIMEOUT,
    nIdn      := nIdn,
    eCmdControl := eCmdControl
  );
IF NOT fbWriteCommandControl.bBusy THEN
  fbWriteCommandControl(Axis := stNcToPlc, bExecute := FALSE);
  bWriteCommandControl := FALSE;
END_IF
END_IF

```

**3.3.3 FB\_SoEReadCommandState**

The function block FB\_SoEReadCommandState can be used to read the state of a command.

**VAR\_INPUT**

```

VAR_INPUT
  sNetId : T_AmsNetId := '';
  nIdn   : WORD;
  bExecute : BOOL;
  tTimeout : TIME := DEFAULT_ADS_TIMEOUT;
END_VAR

```

**sNetId:** A string containing the AMS network identifier of the PC.

**nIdn:** Parameter number for the command, i.e. "P\_0\_IDN + 160" for executing a P-0-0160 command

**bExecute:** The block is activated by a rising edge at this input.

**tTimeout:** Maximum time allowed for the execution of the function block.

**VAR\_IN\_OUT**

```

VAR_IN_OUT
  Axis : NCTOPLC_AXLESTRUCT; (* reference to NC axis *)
END_VAR

```

**Axis:** Axis structure.

**VAR\_OUTPUT**

```

VAR_OUTPUT
  bBusy      : BOOL;
  bError     : BOOL;
  eCmdState  : E_SoE_CmdState;

```

```

    iAdsErrId    : UINT;
    iSercosErrId : UINT;
END_VAR

```

**bBusy:** This output is set when the function block is activated, and remains set until an acknowledgement is received.

**bError:** This output is set up after the bBusy output has been reset if there has been an error in transmission of the command.

**iAdsErrId:** Supplies the ADS error code associated with the most recently executed command if the bError output is set.

**iSercosErrId:** Supplies the Sercos error code associated with the most recently executed command if the bError output is set.

**dwAttribute:** Supplies the Sercos parameter attribute.

**eCmdState:** Supplies the command state

```

    eSoE_CmdState_NotSet =
0
- no command active

    eSoE_CmdState_Set =
1
- command set (prepared) but (not yet) executed

    eSoE_CmdState_Executed =
2
- command was executed

    eSoE_CmdState_SetEnabledExecuted =
3
- command set (prepared) and executed

    eSoE_CmdState_SetAndInterrupted =
5
- command was set but interrupted

    eSoE_CmdState_SetEnabledNotExecuted = 7 -
command execution is still active

    eSoE_CmdState_Error =
15
- error during command execution, switched to error state

```

## Sample

```


fbReadCommandState : FB_SoEReadCommandState;
bReadCommandState  : BOOL;
nIdn                : WORD;
eCmdState           : E_SoE_CmdState;

(* NcAxis *)
stNcToPlc AT %I* : NCTOPLC_AXLESTRUCT;
IF bReadCommandState THEN
    nIdn := P_0_IDN + 160;
    fbReadCommandState(
        Axis      := stNcToPlc,
        bExecute  := TRUE,
        tTimeout  := DEFAULT_ADS_TIMEOUT,
        nIdn      := nIdn,
        eCmdState => eCmdState
    );
    IF NOT fbReadCommandState.bBusy THEN
        fbReadCommandState(Axis := stNcToPlc, bExecute := FALSE);
        bReadCommandState := FALSE;
    END_IF
END_IF

```

## 3.4 Diagnosis FB

### 3.4.1 FB\_SoEReadDiagMessage



The functionblock FB\_SoEReadDiagMessage can be used to read the diagnose message as a Sercos-String (S-0-0095).

#### VAR\_INPUT

```
VAR_INPUT
  sNetId   : T_AmsNetId := '';
  bExecute : BOOL;
  tTimeout : TIME := DEFAULT_ADS_TIMEOUT;
END_VAR
```

**sNetId:** A string containing the AMS network identifier of the PC.

**bExecute:** The block is activated by a rising edge at this input.

**tTimeout:** Maximum time allowed for the execution of the function block.

#### VAR\_IN\_OUT

```
VAR_IN_OUT
  Axis : NCTOPLC_AXLESTRUCT; (* reference to NC axis *)
END_VAR
```

**Axis:** Axis structure.

#### VAR\_OUTPUT

```
VAR_OUTPUT
  bBusy       : BOOL;
  bError      : BOOL;
  iAdsErrId   : UINT;
  iSercosErrId : UINT;
  sDiagMessage : ST_SoE_String;
  dwAttribute  : DWORD;
END_VAR
```

**bBusy:** This output is set when the function block is activated, and remains set until an acknowledgement is received.

**bError:** This output is set up after the bBusy output has been reset if there has been an error in transmission of the command.

**iAdsErrId:** Supplies the ADS error code associated with the most recently executed command if the bError output is set.

**iSercosErrId:** Supplies the Sercos error code associated with the most recently executed command if the bError output is set.

**dwAttribute:** Supplies the Sercos parameter attribute.

**sDiagMessage:** Supplies the diagnostic message.




**Sample**

```
fbDiagMessage : FB_SoEReadDiagMessage;
bDiagMessage  : BOOL;
sDiagMessage  : ST_SoE_String;

(* NcAxis *)
stNcToPlc AT %I* : NCTOPLC_AXLESTRUCT;
IF bDiagMessage THEN
  fbDiagMessage(
    Axis      := stNcToPlc,
    bExecute  := TRUE,
    tTimeout  := DEFAULT_ADS_TIMEOUT,
    sDiagMessage=> sDiagMessage
  );
IF NOT fbDiagMessage.bBusy THEN
  fbDiagMessage(Axis := stNcToPlc, bExecute := FALSE);
  bDiagMessage := FALSE;
END_IF
END_IF
```

**3.4.2 FB\_SoEReadDiagNumber**



The functionblock FB\_SoEReadDiagNumber can be used to read the actual diagnose number as UDINT (S-0-0390).

**VAR\_INPUT**

```
VAR_INPUT
  sNetId   : T_AmsNetId := '';
  bExecute : BOOL;
  tTimeout : TIME := DEFAULT_ADS_TIMEOUT;
END_VAR
```

**sNetId:** A string containing the AMS network identifier of the PC.

**bExecute:** The block is activated by a rising edge at this input.

**tTimeout:** Maximum time allowed for the execution of the function block.

**VAR\_IN\_OUT**

```
VAR_IN_OUT
  Axis : NCTOPLC_AXLESTRUCT; (* reference to NC axis *)
END_VAR
```

**Axis:** Axis structure.

**VAR\_OUTPUT**

```
VAR_OUTPUT
  bBusy      : BOOL;
  bError     : BOOL;
  iAdsErrId  : UINT;
  iSercosErrId : UINT;
```

```

    iDiagNumber    : UDINT;
    dwAttribute    : DWORD;
END_VAR

```

**bBusy:** This output is set when the function block is activated, and remains set until an acknowledgement is received.

**bError:** This output is set up after the bBusy output has been reset if there has been an error in transmission of the command.

**iAdsErrId:** Supplies the ADS error code associated with the most recently executed command if the bError output is set.

**iSercosErrId:** Supplies the Sercos error code associated with the most recently executed command if the bError output is set.

**dwAttribute:** Supplies the Sercos parameter attribute.

**iDiagNumber:** Supplies the diagnostic number.

### Sample


```

fbDiagNumber : FB_SoEReadDiagNumber;
bDiagNumber  : BOOL;
iDiagNumber  : UDINT;

(* NcAxis *)
stNcToPlc AT %I* : NCTOPLC_AXLESTRUCT;
IF bDiagNumber THEN
    fbDiagNumber(
        Axis      := stNcToPlc,
        bExecute  := TRUE,
        tTimeout  := DEFAULT_ADS_TIMEOUT,
        iDiagNumber => iDiagNumber
    );
IF NOT fbDiagNumber.bBusy THEN
    fbDiagNumber(Axis := stNcToPlc, bExecute := FALSE);
    bDiagNumber := FALSE;
END_IF
END_IF

```

## 3.4.3 FB\_SoEReadDiagNumberList



The functionblock FB\_SoEReadDiagNumberList can be used to read the history of the diagnose numbers as a list (S-0-0375).

### VAR\_INPUT

```

VAR_INPUT
    sNetId      : T_AmsNetId := '';
    bExecute    : BOOL;
    tTimeout    : TIME := DEFAULT_ADS_TIMEOUT;
    piDiagNumber : POINTER TO ST_SoE_DiagNumList;
    iSize       : UDINT;
END_VAR

```

**sNetId:** A string containing the AMS network identifier of the PC.

**bExecute:** The block is activated by a rising edge at this input.

**tTimeout:** Maximum time allowed for the execution of the function block.

**piDiagNumber:** Pointer to the list of the last max. 30 error numbers. The list consists of the actual and maximum number of bytes in the list, and of the last 30 list entries

**iSize:** Size of the list in bytes (as Sizeof())

## VAR\_IN\_OUT

```
VAR_IN_OUT
  Axis : NCTOPLC_AXLESTRUCT; (* reference to NC axis *)
END_VAR
```

**Axis:** Axis structure.

## VAR\_OUTPUT

```
VAR_OUTPUT
  bBusy      : BOOL;
  bError     : BOOL;
  iAdsErrId  : UINT;
  iSercosErrId : UINT;
  dwAttribute : DWORD;
END_VAR
```

**bBusy:** This output is set when the function block is activated and remains set until an acknowledgement is received.

**bError:** This output is set up after the bBusy output has been reset if there has been an error in transmission of the command.

**iAdsErrId:** Supplies the ADS error code associated with the most recently executed command if the bError output is set.

**iSercosErrId:** Supplies the Sercos error code associated with the most recently executed command if the bError output is set.


**dwAttribute:** Supplies the Sercos parameter attribute.

## Sample

```
fbDiagNumberList : FB_SoEReadDiagNumberList;
bDiagNumberList  : BOOL;
stDiagNumberList : ST_SoE_DiagNumList;

(* NcAxis *)
stNcToPlc AT %I* : NCTOPLC_AXLESTRUCT;
IF bDiagNumberList THEN
  fbDiagNumberList(
    Axis      := stNcToPlc,
    bExecute := TRUE,
    tTimeout := DEFAULT_ADS_TIMEOUT,
    piDiagNumber:= ADR(stDiagNumberList),
    iSize := SIZEOF(stDiagNumberList),
  );
  IF NOT fbDiagNumberList.bBusy THEN
    fbDiagNumberList(Axis := stNcToPlc, bExecute := FALSE);
    bDiagNumberList := FALSE;
  END_IF
END_IF
```

### 3.4.4 FB\_SoEReadClassXDiag



The function block FB\_SoEReadClassXDiag can be used to read the actual Class 1 Diagnose (S-0-0011) ... Class 3 Diagnose (S-0-0013) as a WORD. There is a conversion function F\_ConvWordToSTAX5000C1D for evaluation of the Class 1 Diagnose as a structure ST\_AX5000\_C1D. See Documentation of TcDrive.lib.

#### VAR\_INPUT

```
VAR_INPUT
  sNetId      : T_AmsNetId := '';
  bExecute    : BOOL;
  iDiagClass  : USINT:= 1; (* 1: C1D (S-0-0011) is default, 2: C2D (S-0-0012), 3: C3D (S-0-0013) *)
  tTimeout    : TIME := DEFAULT_ADS_TIMEOUT;
END_VAR
```

**sNetId:** A string containing the AMS network identifier of the PC.

**bExecute:** The block is activated by a rising edge at this input.

**iDiagClass:** Selects which diagnose should be read. The diagnose info can be different with different drive vendors. Not always all diagnose parameters (C1D ... C3D) or all bits in these parameters are implemented.

1: Error: Class 1 Diag (S-0-0011)

2: Warning: Class 2 Diag (S-0-0012)

3: Informationen: Class 3 Diag (S-0-0013)

**tTimeout:** Maximum time allowed for the execution of the function block.

#### VAR\_IN\_OUT

```
VAR_IN_OUT
  Axis : NCTOPLC_AXLESTRUCT; (* reference to NC axis *)
END_VAR
```

**Axis:** Axis structure.

#### VAR\_OUTPUT

```
VAR_OUTPUT
  bBusy      : BOOL;
  bError     : BOOL;
  iAdsErrId  : UINT;
  iSercosErrId : UINT;
  wClassXDiag : WORD;
  dwAttribute : DWORD;
END_VAR
```

**bBusy:** This output is set when the function block is activated, and remains set until an acknowledgement is received.

**bError:** This output is set up after the bBusy output has been reset if there has been an error in transmission of the command.

**iAdsErrId:** Supplies the ADS error code associated with the most recently executed command if the bError output is set.

**iSercosErrId:** Supplies the Sercos error code associated with the most recently executed command if the bError output is set.

**wClassXDiag:** Supplies the class X diagnose.

**dwAttribute:** Supplies the Sercos parameter attribute.

**Sample**

```
fbClassXDiag : FB_SoEReadClassXDiag;
bClassXDiag : BOOL;
iDiagClass : USINT := 1;
wClass1Diag : WORD;
stAX5000C1D : ST_AX5000_C1D;
wClass2Diag : WORD;


(* NcAxis *)
stNcToPlc AT %I* : NCTOPLC_AXLESTRUCT;
IF bClassXDiag THEN
  fbClassXDiag(
    Axis := stNcToPlc,
    bExecute := TRUE,
    iDiagClass := iDiagClass,
    tTimeout := DEFAULT_ADS_TIMEOUT
  );
  IF NOT fbClassXDiag.bBusy THEN
    fbClassXDiag(Axis := stNcToPlc, bExecute := FALSE);
    bClassXDiag := FALSE;

    CASE
fbClassXDiag.iDiagClass OF
  1:
    wClass1Diag := fbClassXDiag.wClassXDiag;
    stAX5000C1D := F_ConvWordToSTAX5000C1D(wClass1Diag);

  2:
    wClass2Diag := fbClassXDiag.wClassXDiag;
  END_CASE
  END_IF
END_IF
```

### 3.5 FB for current values

#### 3.5.1 FB\_SoERead



The functionblock **FB\_SoERead** can be used to read a parameter.

**VAR\_INPUT**

```
VAR_INPUT
  sNetId : T_AmsNetId := '';
  nIdn : WORD;
  nElement : BYTE;
  pDstBuf : DWORD;
  cbBufLen : UDINT;
  bExecute : BOOL;
  tTimeout : TIME := DEFAULT_ADS_TIMEOUT;
  sPassword : ST_SoE_String;
END_VAR
```

**sNetId:** A string containing the AMS network identifier of the PC.

**nIdn:** Parameter number for the command, i.e. "S\_0\_IDN + 33" for executing a S-0-0033 command

**nElement:** Shows on which parameter part is to be read, e.g. 16#40 is the value of the parameter.

```

EC_SOE_ELEMENT_DATASTATE :BYTE :=16#01;
EC_SOE_ELEMENT_NAME      :BYTE :=16#02;
EC_SOE_ELEMENT_ATTRIBUTE :BYTE :=16#04;
EC_SOE_ELEMENT_UNIT      :BYTE :=16#08;
EC_SOE_ELEMENT_MIN       :BYTE :=16#10;
EC_SOE_ELEMENT_MAX       :BYTE :=16#20;
EC_SOE_ELEMENT_VALUE     :BYTE :=16#40;
EC_SOE_ELEMENT_DEFAULT   :BYTE :=16#80;

```

**pSrcBuf:** Contains the address of the buffer containing the data to be read.

**cbBufLen:** The maximum available buffer size for the data to be read, in bytes.

**bExecute:** The block is activated by a rising edge at this input.

**tTimeout:** Maximum time allowed for the execution of the function block.

**bExecute:** The block is activated by a rising edge at this input.

**tTimeout:** Maximum time allowed for the execution of the function block.

## VAR\_IN\_OUT

```

VAR_IN_OUT
  Axis : NCTOPLC_AXLESTRUCT; (* reference to NC axis *)
END_VAR

```

**Axis:** Axis structure.

## VAR\_OUTPUT

```

VAR_OUTPUT
  bBusy      : BOOL;
  bError     : BOOL;
  iAdsErrId  : UINT;
  iSercosErrId : UINT;
  dwAttribute : DWORD;
END_VAR

```

**bBusy:** This output is set when the function block is activated, and remains set until an acknowledgement is received.

**bError:** This output is set up after the bBusy output has been reset if there has been an error in transmission of the command.

**iAdsErrId:** Supplies the ADS error code associated with the most recently executed command if the bError output is set.

**iSercosErrId:** Supplies the Sercos error code associated with the most recently executed command if the bError output is set.

**dwAttribute:** Supplies the Sercos parameter attribute.

## Sample

```

fbRead : FB_SoERead;
bRead  : BOOL;
iReadValue : UINT;

(* NcAxis *)
stNcToPlc AT %I* : NCTOPLC_AXLESTRUCT;
IF bRead THEN
  nIdn := S_0_IDN + 33;
  fbRead(
    Axis      := stNcToPlc,
    nIdn      := nIdn,
    nElement  := 16#40,
    pDstBuf   := ADR(iReadValue),
    cbBufLen  := SIZEOF(iReadValue),


```

```

        bExecute := TRUE,
        tTimeout := DEFAULT_ADS_TIMEOUT,
    );
    IF NOT fbRead.bBusy THEN
        fbRead(Axis := stNcToPlc, bExecute := FALSE);
        bRead := FALSE;
    END_IF
END_IF

```

### 3.5.2 FB\_SoEWrite



The functionblock FB\_SoEWrite can be used to write a parameter.

#### VAR\_INPUT

```

VAR_INPUT
    sNetId      : T_AmsNetId := '';
    nIdn        : WORD;
    nElement    : BYTE;
    pSrcBuf     : DWORD;
    cbBufLen    : UDINT;
    bExecute    : BOOL;
    tTimeout    : TIME := DEFAULT_ADS_TIMEOUT;
    sPassword   : ST_SoE_String;
END_VAR

```

**sNetId:** A string containing the AMS network identifier of the PC.

**nIdn:** Parameter number for the command, i.e. "S\_0\_IDN + 47" for executing a S-0-0047 command

**nElement:** Shows on which parameter part is to be read, e.g. 16#40 is the value of the parameter. Most times only write access on this value is possible, other parameter parts are write-protected.

```

EC_SOE_ELEMENT_DATASTATE :BYTE :=16#01;
EC_SOE_ELEMENT_NAME      :BYTE :=16#02;
EC_SOE_ELEMENT_ATTRIBUTE :BYTE :=16#04;
EC_SOE_ELEMENT_UNIT      :BYTE :=16#08;
EC_SOE_ELEMENT_MIN       :BYTE :=16#10;
EC_SOE_ELEMENT_MAX       :BYTE :=16#20;
EC_SOE_ELEMENT_VALUE     :BYTE :=16#40;
EC_SOE_ELEMENT_DEFAULT   :BYTE :=16#80;

```

**pSrcBuf:**Contains the address of the buffer containing the data to be send.

**cbBufLen:**The maximum available buffer size for the data to be written, in bytes.

**bExecute:** The block is activated by a rising edge at this input.

**tTimeout:** Maximum time allowed for the execution of the function block.

**sPassword:** contains the password as Sercos-String. Not yet used. The password has to be written with [FB SoEWritePassword](#) [► 10].

**VAR\_IN\_OUT**

```
VAR_IN_OUT
  Axis : NCTOPLC_AXLESTRUCT; (* reference to NC axis *)
END_VAR
```

**Axis:** Axis structure.

**VAR\_OUTPUT**

```
VAR_OUTPUT
  bBusy      : BOOL;
  bError     : BOOL;
  iAdsErrId  : UINT;
  iSercosErrId : UINT;
END_VAR
```

**bBusy:** This output is set when the function block is activated, and remains set until an acknowledgement is received.

**bError:** This output is set up after the bBusy output has been reset if there has been an error in transmission of the command.

**iAdsErrId:** Supplies the ADS error code associated with the most recently executed command if the bError output is set.


**iSercosErrId:** Supplies the Sercos error code associated with the most recently executed command if the bError output is set.

**Sample**

```
fbWrite : FB_SoEWrite;
bWrite  : BOOL;
iWriteValue : UINT;
sPassword : ST_SoE_String;

(* NcAxis *)
stNcToPlc AT %I* : NCTOPLC_AXLESTRUCT;
IF bWrite THEN
  nIdn := S_0_IDN + 33;
  fbWrite(
    Axis      := stNcToPlc,
    nIdn      := nIdn,
    nElement  := 16#40,
    pSrcBuf   := ADR(iWriteValue),
    cbBufLen  := SIZEOF(iWriteValue),
    sPassword := sPassword,
    bExecute  := TRUE,
    tTimeout  := DEFAULT_ADS_TIMEOUT,
  );
  IF NOT fbWrite.bBusy THEN
    fbWrite(Axis := stNcToPlc, bExecute := FALSE);
    bWrite := FALSE;
  END_IF
END_IF
```

**3.5.3 FB\_SoEReadAmplifierTemperature**





The functionblock FB\_SoEReadAmplifierTemperature can be used to read the amplifier temperature (S-0-0384).

### VAR\_INPUT

```
VAR_INPUT
  sNetId    : T_AmsNetId := '';
  bExecute  : BOOL;
  tTimeout  : TIME := DEFAULT_ADS_TIMEOUT;
END_VAR
```

**sNetId:** A string containing the AMS network identifier of the PC.

**bExecute:** The block is activated by a rising edge at this input.

**tTimeout:** Maximum time allowed for the execution of the function block.

### VAR\_IN\_OUT

```
VAR_IN_OUT
  Axis : NCTOPLC_AXLESTRUCT; (* reference to NC axis *)
END_VAR
```

**Axis:** Axis structure.

### VAR\_OUTPUT

```
VAR_OUTPUT
  bBusy           : BOOL;
  bError          : BOOL;
  iAdsErrId       : UINT;
  iSercosErrId    : UINT;
  fAmplifierTemperature : REAL;
  dwAttribute     : DWORD;
END_VAR
```

**bBusy:** This output is set when the function block is activated, and remains set until an acknowledgement is received.

**bError:** This output is set up after the bBusy output has been reset if there has been an error in transmission of the command.

**iAdsErrId:** Supplies the ADS error code associated with the most recently executed command if the bError output is set.

**iSercosErrId:** Supplies the Sercos error code associated with the most recently executed command if the bError output is set.

**dwAttribute:** Supplies the Sercos parameter attribute.


**fAmplifierTemperature:** Supplies the amplifier temperature (e.g. 26.2 means to 26.2°C).

### Sample

```
fbReadAmplifierTemp : FB_SoEReadAmplifierTemperature;
bReadAmplifierTemp  : BOOL;
fAmplifierTemperature : REAL;

(* NcAxis *)
stNcToPlc AT %I* : NCTOPLC_AXLESTRUCT;
IF bReadAmplifierTemp THEN
  fbReadAmplifierTemp (
    Axis      := stNcToPlc,
    bExecute  := TRUE,
    tTimeout  := DEFAULT_ADS_TIMEOUT,
    fAmplifierTemperature=>fAmplifierTemperature
  );
IF NOT fbReadAmplifierTemp.bBusy THEN
  fbReadAmplifierTemp(Axis := stNcToPlc, bExecute := FALSE);
  bReadAmplifierTemp := FALSE;
END_IF
END_IF
```

### 3.5.4 FB\_SoEReadMotorTemperature



The functionblock FB\_SoEReadMotorTemperature can be used to read the temperature of the motor (S-0-0383). If the motor does not contain a temperature sensor then the FB reports 0.0, means 0.0°C.

#### VAR\_INPUT

```
VAR_INPUT
  sNetId    : T_AmsNetId := '';
  bExecute  : BOOL;
  tTimeout  : TIME := DEFAULT_ADS_TIMEOUT;
END_VAR
```

**sNetId:** A string containing the AMS network identifier of the PC.

**bExecute:** The block is activated by a rising edge at this input.

**tTimeout:** Maximum time allowed for the execution of the function block.

#### VAR\_IN\_OUT

```
VAR_IN_OUT
  Axis : NCTOPLC_AXLESTRUCT; (* reference to NC axis *)
END_VAR
```

**Axis:** Axis structure.

#### VAR\_OUTPUT

```
VAR_OUTPUT
  bBusy      : BOOL;
  bError     : BOOL;
  iAdsErrId  : UINT;
  iSercosErrId : UINT;
  fMotorTemperature : REAL;
  dwAttribute : DWORD;
END_VAR
```

**bBusy:** This output is set when the function block is activated, and remains set until an acknowledgement is received.

**bError:** This output is set up after the bBusy output has been reset if there has been an error in transmission of the command.

**iAdsErrId:** Supplies the ADS error code associated with the most recently executed command if the bError output is set.

**iSercosErrId:** Supplies the Sercos error code associated with the most recently executed command if the bError output is set.

**dwAttribute:** Supplies the Sercos parameter attribute.


**fMotorTemperature:** Supplies the motor temperature (i.e. 30.5 means 30.5°C). If the motor does not contain a temperature sensor then the value is 0.0, means 0.0°C.

**Sample**

```
fbReadMotorTemp :FB_SoEReadMotorTemperature;
bReadMotorTemp : BOOL;
fMotorTemperature : REAL;

(* NcAxis *)
stNcToPlc AT %I* : NCTOPLC_AXLESTRUCT;
IF bReadMotorTemp AND NOT bInit THEN
  fbReadMotorTemp(
    Axis := stNcToPlc,
    bExecute := TRUE,
    tTimeout := DEFAULT_ADS_TIMEOUT,
    fMotorTemperature=>fMotorTemperature
  );
IF NOT fbReadMotorTemp.bBusy THEN
  fbReadMotorTemp(Axis := stNcToPlc, bExecute := FALSE);
  bReadMotorTemp := FALSE;
END_IF
END_IF
```

**3.5.5 FB\_SoEReadDcBusCurrent**



The functionblock FB\_SoEAX5000ReadDcBusCurrent\_ByDriveRef can be used to read the DC-Bus-Current (S-0-0381).

**VAR\_INPUT**

```
VAR_INPUT
  sNetId : T_AmsNetId := '';
  bExecute : BOOL;
  tTimeout : TIME := DEFAULT_ADS_TIMEOUT;
END_VAR
```

- sNetId:** A string containing the AMS network identifier of the PC.
- bExecute:** The block is activated by a rising edge at this input.
- tTimeout:** Maximum time allowed for the execution of the function block.

**VAR\_IN\_OUT**

```
VAR_IN_OUT
  Axis : NCTOPLC_AXLESTRUCT; (* reference to NC axis *)
END_VAR
```

**Axis:** Axis structure.

**VAR\_OUTPUT**

```
VAR_OUTPUT
  bBusy : BOOL;
  bError : BOOL;
  iAdsErrId : UINT;
  iSercosErrId : UINT;
  fDcBusCurrent : REAL;
  dwAttribute : DWORD;
END_VAR
```

**bBusy:** This output is set when the function block is activated, and remains set until an acknowledgement is received.

**bError:** This output is set up after the bBusy output has been reset if there has been an error in transmission of the command.

**iAdsErrId:** Supplies the ADS error code associated with the most recently executed command if the bError output is set.

**iSercosErrId:** Supplies the Sercos error code associated with the most recently executed command if the bError output is set.

**dwAttribute:** Supplies the Sercos parameter attribute.


**fDcBusCurrent:** Supplies the DC-Bus-Current (i.e. 2.040 means 2.040A).

### Sample

```
fbReadDcBusCurrent : FB_SoEReadDcBusCurrent_ByDriveRef;
bReadDcBusCurrent  : BOOL;
fDcBusCurrent      : REAL;

(* NcAxis *)
stNcToPlc AT %I* : NCTOPLC_AXLESTRUCT;
IF bReadDcBusCurrent THEN
  fbReadDcBusCurrent(
    Axis      := stNcToPlc,
    bExecute  := TRUE,
    tTimeout  := DEFAULT_ADS_TIMEOUT,
    fDcBusCurrent=>fDcBusCurrent
  );
IF NOT fbReadDcBusCurrent.bBusy THEN
  fbReadDcBusCurrent(Axis := stNcToPlc, bExecute := FALSE);
  bReadDcBusCurrent := FALSE;
END_IF
END_IF
```

## 3.5.6 FB\_SoEReadDcBusVoltage



The function block FB\_SoEReadDcBusVoltage can be used to read the DC-Bus-Voltage of the amplifier (S-0-0380).

### VAR\_INPUT

```
VAR_INPUT
  sNetId   : T_AmsNetId := '';
  bExecute : BOOL;
  tTimeout : TIME := DEFAULT_ADS_TIMEOUT;
END_VAR
```

**sNetId:** A string containing the AMS network identifier of the PC.

**bExecute:** The block is activated by a rising edge at this input.

**tTimeout:** Maximum time allowed for the execution of the function block.

**VAR\_IN\_OUT**

```
VAR_IN_OUT
  Axis : NCTOPLC_AXLESTRUCT; (* reference to NC axis *)
END_VAR
```

**Axis:** Axis structure.

**VAR\_OUTPUT**

```
VAR_OUTPUT
  bBusy          : BOOL;
  bError         : BOOL;
  iAdsErrId     : UINT;
  iSercosErrId  : UINT;
  fDcBusVoltage : REAL;
  dwAttribute   : DWORD;
END_VAR
```

**bBusy:** This output is set when the function block is activated, and remains set until an acknowledgement is received.

**bError:** This output is set up after the bBusy output has been reset if there has been an error in transmission of the command.

**iAdsErrId:** Supplies the ADS error code associated with the most recently executed command if the bError output is set.

**iSercosErrId:** Supplies the Sercos error code associated with the most recently executed command if the bError output is set.

**dwAttribute:** Supplies the Sercos parameter attribute.

**fDcBusVoltage:** Supplies the DC-Bus-Voltage (i.e. 294.0 means 294.0V).


**Sample**

```
fbReadDcBusVoltage : FB_SoEReadDcBusVoltage;
bReadDcBusVoltage  : BOOL;
fDcBusVoltage      : REAL;

(* NcAxis *)
stNcToPlc AT %I* : NCTOPLC_AXLESTRUCT;
IF bReadDcBusVoltage THEN
  fbReadDcBusVoltage(
    Axis      := stNcToPlc,
    bExecute  := TRUE,
    tTimeout  := DEFAULT_ADS_TIMEOUT,
    fDcBusVoltage=>fDcBusVoltage
  );
  IF NOT fbReadDcBusVoltage.bBusy THEN
    fbReadDcBusVoltage(Axis := stNcToPlc, bExecute := FALSE);
    bReadDcBusVoltage := FALSE;
  END_IF
END_IF
```

## 4 AX5000 specific FB

### 4.1 FB\_SoEAX5000ReadActMainVoltage



The functionblock FB\_SoEAX5000ReadActMainVoltage can be used to read the main voltage (P-0-0200) of the AX5000.

#### VAR\_INPUT

```
VAR_INPUT
  sNetId : T_AmsNetId := '';
  bExecute : BOOL;
  tTimeout : TIME := DEFAULT_ADS_TIMEOUT;
END_VAR
```

**sNetId:** A string containing the AMS network identifier of the PC.

**bExecute:** The block is activated by a rising edge at this input.

**tTimeout:** Maximum time allowed for the execution of the function block.

#### VAR\_IN\_OUT

```
VAR_IN_OUT
  Axis : NCTOPLC_AXLESTRUCT; (* reference to NC axis *)
END_VAR
```

**Axis:** Axis structure.

#### VAR\_OUTPUT

```
VAR_OUTPUT
  bBusy : BOOL;
  bError : BOOL;
  iAdsErrId : UINT;
  iSercosErrId : UINT;
  dwAttribute : DWORD;
  fActualMainVoltage : LREAL;
END_VAR
```

**bBusy:** This output is set when the function block is activated, and remains set until an acknowledgement is received.

**bError:** This output is set up after the bBusy output has been reset if there has been an error in transmission of the command.

**iAdsErrId:** Supplies the ADS error code associated with the most recently executed command if the bError output is set.

**iSercosErrId:** Supplies the Sercos error code associated with the most recently executed command if the bError output is set.

**dwAttribute:** Supplies the Sercos parameter attribute.


**fActualMainVoltage:** Supplies the main voltage of the AX5000 (i.e. 303.0 means 303.0V ).

**Sample**

```
fbReadActMainVoltage : FB_SoEAX5000ReadActMainVoltage;
bReadActMainVoltage : BOOL;
fActualMainVoltage : REAL;

(* NcAxis *)
stNcToPlc AT %I* : NCTOPLC_AXLESTRUCT;
IF bReadActMainVoltage THEN
  fbReadActMainVoltage(
    Axis := stNcToPlc,
    bExecute := TRUE,
    tTimeout := DEFAULT_ADS_TIMEOUT,
    fActualMainVoltage=>fActualMainVoltage
  );
  IF NOT fbReadActMainVoltage.bBusy THEN
    fbReadActMainVoltage(Axis := stNcToPlc, bExecute := FALSE);
    bReadActMainVoltage := FALSE;
  END_IF
END_IF
```

## 4.2 FB\_SoEAX5000SetMotorCtrlWord



The functionblock FB\_SoEAX5000SetMotorCtrlWord can be used to set the ForceLock-Bit (Bit 0) or the ForceUnlock-Bit in the motor control word (P-0-0096), in order to set or release the brake. The brake is set and released automatically via the enable of the drive.

TheForceLock-Bit can be used to set the brake independent of the enable, the ForceUnlock-Bit can be used to release the brake independent of the enable. If ForceLock and ForceUnlock are set simultaneously then the ForceLock (brake locked) has the higher priority.

**VAR\_INPUT**

```
VAR_INPUT
  sNetId : T_AmsNetId := '';
  bExecute : BOOL;
  tTimeout : TIME := DEFAULT_ADS_TIMEOUT;
  bForceLock : BOOL;
  bForceUnlock : BOOL;
END_VAR
```

**sNetId:** A string containing the AMS network identifier of the PC.

**bExecute:** The block is activated by a rising edge at this input.

**tTimeout:** Maximum time allowed for the execution of the function block.

**bForceLock:** Lock the brake independent of the enable.

**bForceUnlock:** Release (unlock) the brake independent of the enable.

**VAR\_IN\_OUT**

```
VAR_IN_OUT
  Axis : NCTOPLC_AXLESTRUCT; (* reference to NC axis *)
END_VAR
```

**Axis:** Axis structure.

**VAR\_OUTPUT**

```

VAR_OUTPUT
  bBusy      : BOOL;
  bError     : BOOL;
  iAdsErrId  : UINT;
  iSercosErrId : UINT;
END_VAR

```

**bBusy:** This output is set when the function block is activated, and remains set until an acknowledgement is received.

**bError:** This output is set up after the bBusy output has been reset if there has been an error in transmission of the command.

**iAdsErrId:** Supplies the ADS error code associated with the most recently executed command if the bError output is set.

**iSercosErrId:** Supplies the Sercos error code associated with the most recently executed command if the bError output is set.

**Sample**


```

fbSetMotorCtrlWord : FB_SoEAX5000SetMotorCtrlWord;
bSetMotorCtrlWord  : BOOL;
bForceLock         : BOOL;
bForceUnlock       : BOOL;

(* NcAxis *)
stNcToPlc AT %I* : NCTOPLC_AXLESTRUCT;
IF bSetMotorCtrlWord THEN
  fbSetMotorCtrlWord(
    Axis      := stNcToPlc,
    bExecute  := TRUE,
    tTimeout  := DEFAULT_ADS_TIMEOUT,
    bForceLock := bForceLock,
    bForceUnlock := bForceUnlock
  );

  IF NOT fbSetMotorCtrlWord.bBusy THEN
    fbSetMotorCtrlWord(Axis := stNcToPlc, bExecute := FALSE);
    bSetMotorCtrlWord := FALSE;
  END_IF
END_IF

```

**4.3 FB\_SoEAX5000FirmwareUpdate**

The functionblock **FB\_SoEAX5000FirmwareUpdate** can be used to check and update the firmware of the AX5000 to a requested version (revision and build) or to the newest build of the configured revision.

In order to update the following sequence is executed:

- get configured slave type, i.e. AX5103-0000-0010
- get scanned slave type for the slave address, i.e. AX5103-0000-0009
- get current slave firmware, i.e. v1.05\_b0009
- compare configured and scanned slave (number of channels, current, revision, firmware)
- create firmware files name and search for the file



- update firmware (if required)
- rescan slave
- switch the slave to the requested EtherCAT state

A successful update finishes with **eFwUpdateState = eFwU\_FwUpdateDone**. If the update is not required, then the state returns **eFwUpdateState = eFwU\_NoFwUpdateRequired**. The firmware update is executed via the channel of the drive (A=0 or B=1) set in **stDriveRef**. With two channel devices, the firmware update can only be executed via one of the channels. The other channel signals **eFwUpdateState = eFwU\_UpdateViaOtherChannelActive** or **eFwU\_UpdateViaOtherChannel**.

During the firmware update (**eFwUpdateState = eFwU\_FwUpdateInProgress**) the update progress is reported via **LoadProgress in percent**.

**Attention: During the update the PLC and TwinCAT have to stay in RUN mode, the EtherCAT connection must be maintained and the AX5000 must stay powered up!**

**VAR\_INPUT**

```
VAR_INPUT
  sNetId      : T_AmsNetId;
  bExecute    : BOOL;
  sFirmwareVersion : STRING(20); (* version string vx.yy_bnnnn, e.g. "v1.05_b0009" for v1.05 Build 0009 *)
  sFirmwarePath : T_MaxString; (* drive:\path, e.g. "C:\TwinCAT\Io\TcDriveManager\FirmwarePool" *)
  iReqEcState  : UINT := EC_DEVICE_STATE_OP;
  tTimeout     : TIME := DEFAULT_ADS_TIMEOUT;
END_VAR
```

**bExecute:** The block is activated by a rising edge at this input.

**sFirmwareVersion:** The required firmware version in form of vx.yy\_bnnnn, i.e. "v1.05\_b0009" for version v1.05 build 0009.

- Release builds:
- "v1.05\_b0009" for specific build, i.e. v1.05 Build 0009
  - "v1.05\_b00???" newstest build of a version, i.e. v1.05
  - "v1.??\_b00???" newstest build of a major version, i.e. v1
  - "v?.??\_b00???" newstest version and newstest build
  - "" newstest version and newstest build

- Customer specific firmware builds:
- "v1.05\_b1009" for specific build, i.e. v1.05 Build 1009
  - "v1.05\_b10???" newstest build of a version, i.e. v1.05
  - "v1.??\_b10???" newstest build of a major version, i.e. v1
  - "v?.??\_b10???" newstest version and newstest build
  - ...

- "v1.05\_b8909" for specific build, i.e. v1.05 Build 8909
- "v1.05\_b89???" newstest build of a version, i.e. v1.05
- "v1.??\_b89???" newstest build of a major version, i.e. v1
- "v?.??\_b89???" newstest version and newstest build

- Debug builds:
- "v1.05\_b9009" for specific build, i.e. v1.05 Build 9009
  - "v1.05\_b90???" newstest build of a version, i.e. v1.05
  - "v1.??\_b90???" newstest build of a major version, i.e. v1
  - "v?.??\_b90???" newstest version and newstest build

**sFirmwarePath:** The path for the firmware pool, where the firmware files are located, i.e. "C:\TwinCAT\Io\TcDriveManager\FirmwarePool".

**sNetIdIPC:** AMS-NetID of the controller (IPC).

**iReqEcState:** Requested EtherCAT state after the update (only if an update is executed). The states are defined in the TcEtherCAT.lib as globale constants.

**tTimeout:** The firmware update can take a few minutes, the timeout here defines the timeout for internal ADS instances.

## VAR\_IN\_OUT

```
VAR_IN_OUT
  Axis : NCTOPLC_AXLESTRUCT; (* reference to NC axis *)
END_VAR
```

**Axis:** Axis structure.

## VAR\_OUTPUT

```
VAR_OUTPUT
  bBusy           : BOOL;
  bError          : BOOL;
  iAdsErrId       : UINT;
  iSercosErrId    : UINT;
  iDiagNumber     : UDINT;
  eFwUpdateState  : E_FwUpdateState;
  iLoadProgress   : INT;
  sSelectedFirmwareFile : STRING(MAX_STRING_LENGTH); (* found firmware file, e.g.
"AX5yxx_xxxx_0010_v1_05_b0009.efw" *)
END_VAR
```

**bBusy:** This output is set when the function block is activated and remains set until an acknowledgement is received.

**bError:** This output is set up after the bBusy output has been reset if there has been an error in transmission of the command.

**iAdsErrId:** Supplies the ADS error code associated with the most recently executed command if the bError output is set.

**iSercosErrId:** Supplies the Sercos error code associated with the most recently executed command if the bError output is set.

**iDiagNumber:** Supplies the drive error code associated with the most recently executed firmware update if the bError output is set.

**eFwUpdateState:** Supplies the status of the firmware update. See [E\\_FwUpdateState](#) [► 37].

**iLoadProgress:** Supplies the progress of the firmware load in percent.

**sSelectedFirmwareFile:** Supplies the name of the searched firmware file.

## Sample

```
VAR CONSTANT
  iNumOfDrives      : INT := 2;
END_VAR

VAR
  fbFirmwareUpdate  : ARRAY[1..iNumOfDrives] OF FB_SoEAX5000FirmwareUpdate;
  stNcToPlc AT %I*  : ARRAY[1..iNumOfDrives] OF NCTOPLC_AXLESTRUCT;
  sFirmwareVersion  : ARRAY[1..iNumOfDrives] OF STRING(20) (* :=2('v1.04_b0002') *);

  eFwUpdateState    : ARRAY[1..iNumOfDrives] OF E_FwUpdateState;
  sSelectedFirmwareFile: ARRAY [1..iNumOfDrives] OF STRING(MAX_STRING_LENGTH);
  iUpdateState      : INT;
  bExecute          : BOOL;
  sNetIdIPC         : T_AmsNetId := '';
  sFirmwarePath     : T_MaxString := 'C:\TwinCAT\Io\TcDriveManager\FirmwarePool';
  I                 : INT;
  bAnyBusy          : BOOL;
  bAnyError         : BOOL;
END_VAR
CASE iUpdateState OF
0:
  IF bExecute THEN
    iUpdateState := 1;
  END_IF
1:
```

```
FOR I := 1 TO iNumOfDrives DO
  fbFirmwareUpdate[I](
    Axis := stNcToPlc[I],
    bExecute := TRUE,
    tTimeout := T#15s,
    sFirmwareVersion := sFirmwareVersion[I],
    sFirmwarePath := sFirmwarePath,
    sNetId := sNetIdIPC,
    iReqEcState := EC_DEVICE_STATE_OP,
    eFwUpdateState => eFwUpdateState[I],
  );
END_FOR
iUpdateState := 2;

2:
bAnyBusy := FALSE;
bAnyError := FALSE;
FOR I := 1 TO iNumOfDrives DO
  fbFirmwareUpdate[I](
    Axis := stNcToPlc[I],
    eFwUpdateState => eFwUpdateState[I],
    sSelectedFirmwareFile => sSelectedFirmwareFile[I],
  );
  IF NOT fbFirmwareUpdate[I].bBusy THEN
    fbFirmwareUpdate[I](bExecute := FALSE, Axis := stNcToPlc[I]);
    IF fbFirmwareUpdate[I].bError THEN
      bAnyError := TRUE;
    END_IF
  ELSE
    bAnyBusy := TRUE;
  END_IF
END_FOR


IF NOT bAnyBusy THEN
  bExecute := FALSE;

  IF NOT bAnyError THEN
    iUpdateState := 0; (* OK *)
  ELSE
    iUpdateState := 3; (* Error *)
  END_IF
END_IF

3:
(* Error handling *)
iUpdateState := 0;

END_CASE
```

## 5 F\_GetVersionTcNcDrive



This function can be used to read PLC library version information.

### FUNCTION F\_GetVersionTcNcDrive : UINT

```
VAR_INPUT
    nVersionElement : INT;
END_VAR
```

**nVersionElement** : Version element to be read. Possible parameters:

- 1 : major number;
- 2 : minor number;
- 3 : revision number;

### Requirements

Development environment	Target system type	PLC libraries to be linked
TwinCAT v2.10.0 Build >= 1329	PC or CX (x86)	TcDrive.lib, TcEtherCAT.lib, TcUtilities.Lib, TcSystem.lib
TwinCAT v2.10.0 Build >= 1329	CX (ARM)	

## 6 E\_FwUpdateState

E\_FwUpdateState describes the state of the firmware update.

```

TYPE E_SoE_CmdState : (
  (* update states *)
  eFwU_NoError := 0,
  eFwU_CheckCfgIdentity,
  eFwU_CheckSlaveCount,
  eFwU_CheckFindSlavePos,
  eFwU_WaitForScan,
  eFwU_ScanningSlaves,
  eFwU_CheckScannedIdentity,
  eFwU_CheckScannedFirmware,
  eFwU_FindFirmwareFile,
  eFwU_WaitForUpdate,
  eFwU_WaitForSlaveState,
  eFwU_StartFwUpdate,
  eFwU_FwUpdateInProgress,
  eFwU_FwUpdateDone,
  eFwU_NoFwUpdateRequired,

  (* not updating via this channel *)
  eFwU_UpdateViaOtherChannelActive,
  eFwU_UpdatedViaOtherChannel,

  (* error states *)
  eFwU_GetSlaveIdentityError := -1,
  eFwU_GetSlaveCountError := -2,
  eFwU_GetSlaveAddrError := -3,
  eFwU_StartScanError := -4,
  eFwU_ScanStateError := -5,
  eFwU_ScanIdentityError := -6,
  eFwU_GetSlaveStateError := -7,
  eFwU_ScanFirmwareError := -8,
  eFwU_FindFileError := -9,
  eFwU_CfgTypeInNoAX5xxx := -10,
  eFwU_ScannedTypeInNoAX5xxx := -11,
  eFwU_ChannelMismatch := -12,
  eFwU_ChannelMismatch_1Cfg_2Scanned := -13,
  eFwU_ChannelMismatch_2Cfg_1Scanned := -14,
  eFwU_CurrentMismatch := -15,
  eFwU_FwUpdateError := -16,
  eFwU_ReqSlaveStateError := -17
);

```

END\_TYPE

Update Status

eFwU\_NoError  
: initial state

eFwU\_CheckCfgIdentity  
: reading of the configured slave type (number of channels, current, revision)

eFwU\_CheckSlaveCount  
: get configured amount of slaves

eFwU\_CheckFindSlavePos  
: search slave address in the master object directory

eFwU\_WaitForScan  
: wait for online scan

eFwU\_ScanningSlaves  
: online scan of slaves

eFwU\_CheckScannedIdentity  
: reading of scanned slave types (number of channels, current, revision)

```
eFwU_CheckScannedFirmware
: get firmware version of the drive

eFwU_FindFirmwareFile
: search for firmware file

eFwU_WaitForUpdate
: wait for updates (short delay before the update)

eFwU_WaitForSlaveState
: get EtherCAT slave state

eFwU_StartFwUpdate
: Start firmware update

eFwU_FwUpdateInProgress
: firmware update active

eFwU_FwUpdateDone
: firmware update succeeded

eFwU_NoFwUpdateRequired
: no firmware update required

    eFwU_UpdateViaOtherChannelActive    : Update
via the other drive channel active

eFwU_UpdatedViaOtherChannel
: Updated via the other drive channel

Update Errors

eFwU_GetSlaveIdentityError
: reading of the configured slave type failed, see iAdsErrId

eFwU_GetSlaveCountError
: get configured amount of slaves failed, see iAdsErrId

eFwU_GetSlaveAddrError
: search slave address in the master object directory failed, see
iAdsErrId

eFwU_StartScanError
: start of online scan of slaves failed, see iAdsErrId

eFwU_ScanStateError
: online scan failed, see iAdsErrId

eFwU_ScanIdentityError
: reading of scanned slave types (number of channels, current,
revision) failed, see iAdsErrId

eFwU_GetSlaveStateError
: get EtherCAT slave state failed, see iAdsErrId

eFwU_ScanFirmwareError
: get firmware version of the drive failed, see iAdsErrId +
iSercosErrId

eFwU_FindFileError
: search for firmware file failed, see iAdsErrId
```

```
eFwU_CfgTypeInNoAX5xxx
: the configured slave is not an AX5000

eFwU_ScannedTypeInNoAX5xxx
: the scanned slave is not an AX5000

eFwU_ChannelMismatch
: The amount of configured and scanned channels of the AX5000 do
not match

    eFwU_ChannelMismatch_1Cfg_2Scanned : one channel
device configured but two channel device found

    eFwU_ChannelMismatch_2Cfg_1Scanned : two channel
device configured but one channel device found

eFwU_CurrentMismatch
: current of the AX5000 type does not match, i.e. AX5103 (3A)
configured but AX5106 (6A) found

eFwU_FwUpdateError
: general update error, see iAdsErrId

eFwU_ReqSlaveStateError
: switching ot requested EtherCAT state failed, see iAdsErrId
```





More Information:  
[www.beckhoff.com/tx1200](http://www.beckhoff.com/tx1200)

Beckhoff Automation GmbH & Co. KG  
Hülshorstweg 20  
33415 Verl  
Germany  
Phone: +49 5246 9630  
[info@beckhoff.com](mailto:info@beckhoff.com)  
[www.beckhoff.com](http://www.beckhoff.com)

